


**Glass Lined Indirect  
Water Heater  
Installation & Operation  
Manual  
Models: GIT040 - GIT119**

**CAUTION:**

The heat transfer medium must be water or other nontoxic fluid having a toxicity rating or class of 1, as listed in Clinical Toxicology of Commercial Products, 5th edition.

The pressure of the heat transfer medium must be limited to a maximum of 30 PSIG by an approved safety or relief valve.



LOW LEAD CONTENT



**Lochinvar**<sup>®</sup>  
HIGH EFFICIENCY BOILERS & WATER HEATERS

**WARNING**

This manual must only be used by a qualified heating installer / service technician. Read all instructions before installing. Perform steps in the order given. Failure to comply could result in severe personal injury, death, or substantial property damage.

Save this manual for future reference.

# Contents

<p><b>HAZARD DEFINITIONS</b> ..... 2</p> <p><b>PLEASE READ BEFORE PROCEEDING</b> ..... 3</p> <p><b>1. GENERAL INFORMATION</b></p> <p>Operating Restrictions..... 4</p> <p>Single-Wall Heat Exchanger ..... 4</p> <p><b>2. PRE-INSTALLATION</b></p> <p>Locating the Tank..... 5</p> <p>Recommended Clearances..... 5</p> <p><b>3. BOILER SIDE PIPING</b></p> <p>Zone with Circulator to Aquastat..... 6</p> <p>Zone with Valve to Aquastat ..... 6</p> <p>DHW Prioritization ..... 6</p> <p>Multiple Tank Connections (Boiler Side)..... 6</p> <p style="padding-left: 20px;">Table 3A - Domestic &amp; Boiler Piping Connection Sizes 6</p> <p>Piping Diagrams..... 7-10</p> <p><b>4. DOMESTIC SIDE (TANK) PIPING</b></p> <p>Basic Domestic Piping ..... 11</p> <p>Multiple Tank Domestic Water Piping..... 11</p> <p>Domestic Water Piping for Distant Fixtures..... 11</p>	<p>Anti-scald Valves (Mixing Valves) ..... 12</p> <p>Install Drain Valve ..... 12</p> <p>Temperature and Pressure (T&amp;P) Relief Valve..... 12</p> <p style="padding-left: 20px;">Table 4A - Minimum Relief Valve (AGA Rating)... 13</p> <p><b>5. WIRING</b></p> <p>Indirect Water Heater Sensor Setup (Knight Boiler)..... 14</p> <p style="padding-left: 20px;">Install and Connect Tank Sensor ..... 14</p> <p>Indirect Water Heater Controlled Using Aquastat and Zone Circulator..... 15</p> <p><b>6. START-UP AND CHECK-OUT</b> ..... 16</p> <p><b>7. MAINTENANCE</b></p> <p>Maintenance Schedule..... 17</p> <p style="padding-left: 20px;">To Fill the Water Heater ..... 17</p> <p style="padding-left: 20px;">To Drain the Water Heater ..... 17</p> <p><b>8. PERFORMANCE DATA</b></p> <p>AHRI Chart..... 18</p> <p>How to Properly Size Your Indirect Water Heater ..... 19</p> <p>Performance Data Charts ..... 20-23</p> <p><b>REVISION NOTES</b>..... Back Cover</p>
--	--

## Hazard definitions

The following defined terms are used throughout this manual to bring attention to the presence of hazards of various risk levels or to important information concerning the life of the product.

** DANGER** DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

** WARNING** WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

** CAUTION** CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**CAUTION** CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

**NOTICE** NOTICE indicates special instructions on installation, operation, or maintenance that are important but not related to personal injury or property damage.

## Please read before proceeding

**WARNING** Installer – Read all instructions before installing. Perform steps in the order given.

Have this indirect water heater serviced/inspected by a qualified service technician, at least annually.

Failure to comply with the above could result in severe personal injury, death or substantial property damage.

**NOTICE** When calling or writing about the appliance – Please have the indirect water heater model and serial number from the indirect water heater rating plate.

Consider piping and installation when determining appliance location.

Any claims for damage or shortage in shipment must be filed immediately against the transportation company by the consignee.

Factory warranty (shipped with appliance) does not apply to appliances improperly installed or improperly operated.

**WARNING** If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

This appliance MUST NOT be installed in any location where gasoline or flammable vapors are likely to be present.

### WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

**WARNING** Failure to adhere to the guidelines on this page can result in severe personal injury, death, or substantial property damage.

### When servicing the indirect water heater –

- To avoid severe burns, allow the appliance to cool before performing maintenance.

### Indirect water heater operation –

- Should overheating occur or gas supply fail to shut off, do not turn off or disconnect electrical supply to circulator. Instead, shut off the gas supply at a location external to the appliance.
- Do not use this appliance if any part has been under water. The possible damage to a flooded appliance can be extensive and present numerous safety hazards. Any appliance that has been under water must be replaced.

The following chart details the relationship of water temperature and time with regard to scald injury and may be used as a guide in determining the safest water temperature for your applications.

APPROXIMATE TIME / TEMPERATURE RELATIONSHIPS IN SCALDS	
120°F	More than 5 minutes
125°F	1 1/2 to 2 minutes
130°F	About 30 seconds
135°F	About 10 seconds
140°F	Less than 5 seconds
145°F	Less than 3 seconds
150°F	About 1 1/2 seconds
155°F	About 1 second



### Hot Water Can Scald!

- Water heated to temperatures for clothes washing, dish washing, and other sanitizing needs can scald and cause permanent injury.
- Children, elderly, and infirm or physically handicapped persons are more likely to be permanently injured by hot water. Never leave them unattended in a bathtub or shower. Never allow small children to use a hot water tap or draw their own bath.
  - If anyone using hot water in the building fits the above description, or if state laws or local codes require certain water temperatures at hot water taps, you must take special precautions:
    - Use lowest possible temperature setting.
    - Install some type of tempering device, such as an automatic mixing valve, at hot water tap or water heater. Automatic mixing valve must be selected and installed according to valve manufacturer's recommendations and instructions.
- Water passing out of drain valves may be extremely hot. To avoid injury:
  - Make sure all connections are tight.
  - Direct water flow away from any person.

Protection Must Be Taken Against Excessive Temperature and Pressure!  
 --Installation of a Temperature & Pressure (T&P) relief valve is required.

# 1 General information

The Lochinvar series indirect water heater (FIG. 1-1) is designed to generate domestic hot water in conjunction with a hot water boiler using forced boiler water circulation. This indirect water heater consists of a tank in which a smooth coil is located (Table 1A). Boiler water is pumped through the coil and heats the water in the tank. This tank is not intended for use in pool heating applications or for heating any fluid other than water. It is also not intended for use in gravity hot water heating systems.

## Operating restrictions:

- Maximum domestic hot water temperature is 194°F.
- Maximum boiler water temperature is 210°F.
- Maximum working pressure for the vessel tank is 150 psig.

## Single-wall heat exchanger

### Uniform plumbing code


Single-wall heat exchangers are permitted if they satisfy all of the following requirements --

1. The heat transfer medium is potable water or contains only substances which are recognized as safe by the U.S. Food and Drug Administration.
2. The pressure of the heat transfer medium is maintained less than the normal minimum operating pressure of the potable water system.
3. The equipment is permanently labeled to indicate that only additives recognized as safe by the FDA shall be used in the heat transfer medium.

Other heat exchanger designs may be permitted where approved by the Administrative Authority.

Component	Material
Tank	Glass Lined Steel
Coil	Glass Lined Steel
Insulation	Polyurethane
Jacket	ABS

Figure 1-1 Lochinvar GIT Series Indirect Water Heater



## 2 Pre-installation

1. The installation must conform to the instructions in this manual and all applicable local, state, provincial, and national codes, laws, regulations, and ordinances. Installations in Canada must conform to B149.2 Installation Code.
2. Be certain the domestic water supply to the tank has physical and chemical characteristics that fall within the limits shown in Table 2A. Where questions exist as to the composition of the water on the job, a qualified water treatment expert should be consulted.

### CAUTION

Water with characteristics outside the limits shown in Table 2A may severely shorten the life of the tank due to corrosion. Damage to tanks in such cases is not covered under warranty.

3. Read and understand all installation requirements in this manual.

Table 2A Water Chemistry Requirements		
Water used in the tank must have characteristics falling within the following limits:		
Characteristic	Min.	Max.
Ph	6.0	8.0
Chloride (PPM)	--	80

## Locating the tank

1. Choose a location for your water heater centralized to the piping system. You must also locate the GIT water heater where it will not be exposed to freezing temperatures. Additionally, you will need to place the water heater so that the controls, drain, and inlet/outlets are easily accessible. This appliance must not be installed outdoors, as it is certified as an indoor appliance, and must also be kept vertical on a level surface.
2. Keep distance between boiler and water heater to a minimum to:
  - a. reduce piping heat loss
  - b. provide minimal friction loss
3. Figure 1-1 on page 4 shows the weights of all the tanks filled with water. Make sure that the location chosen for the tank is capable of supporting it.

### CAUTION

This appliance must be placed where leakage from the relief valve, leakage from the related piping, or leakage from the tank or connections, will not result in damage to the surrounding areas, or to the lower floors of the building. A water heater should always be located in an area with a floor drain or installed in a drain pan suitable for water heaters. Lochinvar shall not be held liable for any such water damage.

4. The tank may be located some distance from the boiler provided the pump is designed to provide the flow called for in Table 3A - Domestic and Boiler Piping Connection Sizes, through the coil. Also, the further the tank is from the boiler, the longer the response of the boiler will be to a call from the tank zone. Insulate piping between the boiler and the tank.

### WARNING

Failure to properly support the tank could result in property damage or personal injury.

## Recommended clearances

The installation location must provide adequate clearances for servicing and proper operation of the water heater. A 12 inch vertical clearance is recommended from the top of the water heater. A zero clearance is allowed for the sides of the water heater. However, boiler and servicing clearances must be figured when locating the water heater.

### 3 Boiler side piping

Figures 3-1 thru 3-4 show typical boiler side piping for several common situations. Regardless of which system is used it is imperative that the flow rates called for in Table 3A are developed through the coil. This requires properly sized piping and a properly sized pump.

The system shown in FIG's 3-1 thru 3-4 are described below:

#### Zone with circulator to Aquastat

This system is like the circulator zone system on a straight heat job except that one of the zones goes to the tank instead of radiation. As on any circulator zone system check valves should be installed in each zone to prevent unwanted circulation through zones which are not calling for heat. Figure 3-1 on page 7 illustrates typical circulator zone piping.

#### Zone with valve to Aquastat

As with the circulator zone system, this system is just like a standard heating zone system except that one of the zones is connected to the tank coil as shown in FIG. 3-2. The system circulator must be large enough to move boiler water through the coil regardless of the flow rate required through the heating zones.

#### DHW prioritization

This piping system is designed to provide direct hot water priority over the other zones in the heating system. When there is a Domestic Hot Water (DHW) call for heat, the Knight control will shut off the boiler circulator and activate the domestic hot water circulator. Once the DHW demand is satisfied, the boiler circulator will be readjusted as demand requires. The circulator must be large enough to move the boiler water through the coils. The recommended piping for a DHW priority system is depicted in FIG. 3-3 on page 9.

#### Multiple tank connections (boiler side)

Multiple tank installations must be done in the "reverse-return" manner. The reason for this is to create the same pressure drop (and therefore, the same flow) through the coil of each tank. The boiler manifold piping must be sized so that each coil has the flow rate called for in Table 3A.


Because the pressure drop through tank coils varies from size to size, it is hard to predict the flow rate that will be developed through each coil when two tanks of different sizes are placed in the same manifold. For this reason it is best not to mix tanks of different sizes in the same zone if their recovery is critical.

Table 3A  
Domestic and Boiler Piping Connection Sizes

MODEL	WATER INLET (NPT)	WATER OUTLET (NPT)	COIL CONNECTION (NPT)	COIL LENGTH (FT)	TUBE DIAMETER (IN)	PRESSURE DROP (FT/HD)			
						5 GPM	8 GPM	12 GPM	14 GPM
GIT040	1	1.25	1	30.8	1.25	0.75	1.7	3.5	5.7
GIT050	1	1.25	1	36.5	1.25	0.85	1.8	3.6	5.8
GIT080	1.5	1.5	1	41.5	1.25	1.2	2.7	5.3	8.9
GIT119	1.5	1.5	1	67.3	1.25	2.5	6.1	12.5	16.4

### 3 Boiler side piping *(continued)*

Figure 3-1 Piping Diagram Zoned with Circulators



**NOTICE**


Please note that these illustrations are meant to show system piping concept only, the installer is responsible for all equipment and detailing required by local codes.

**NOTICE**

Please note that the installer is responsible for ensuring DHW prioritization when piped as a zone.

### 3 Boiler side piping

Figure 3-2 Piping Diagram Zoned with Valves



#### NOTICE


Please note that these illustrations are meant to show system piping concept only, the installer is responsible for all equipment and detailing required by local codes.

#### NOTICE

Please note that the installer is responsible for ensuring DHW prioritization when piped as a zone.

### 3 Boiler side piping *(continued)*

Figure 3-3 Knight Boiler Primary / Secondary Piping




#### NOTICE

Please note that these illustrations are meant to show system piping concept only, the installer is responsible for all equipment and detailing required by local codes.

### 3 Boiler side piping

Figure 3-4 Multiple Tank Connections



IMG001B4

#### NOTICE

Please note that these illustrations are meant to show system piping concept only, the installer is responsible for all equipment and detailing required by local codes.

## 4 Domestic side (tank) piping

### Basic domestic piping

Figure 4-2 on page 14 shows typical domestic water piping for a tank. The function of the components shown are as follows:

- a. Shut-off valves (recommended) - Used to isolate the tank for servicing.
- b. Backflow Preventer (required by some codes) - Used to prevent water from backing out of the tank and into the main potable water supply in the event that inlet water pressure drops.
- c. Expansion Tank (required for thermal expansion) - This expansion tank absorbs the increased volume caused by heating water.

Use an expansion tank designed for use on domestic water systems. Refer to the expansion tank manufacturer's literature for the proper size expansion tank to use.

#### NOTICE

If an expansion tank is used, do not put any valves between the expansion tank and tank inlet.

- d. Unions (optional) - Used to disconnect the tank in the unlikely event that this is necessary.
- e. Drain (required) - Used to drain the tank for inspection or servicing.

### Multiple tank domestic water piping

The two pipe reverse return piping uses more pipe than the two pipe direct return piping, but the flow is more balanced and even in the two pipe reverse return piping layout (see FIG. 3-4).

Each tank must have its own T&P valve. It is recommended that each tank be equipped with its own isolation valves, unions, and drains so that one tank may be removed from the system. If local codes require a backflow preventer, check with the appropriate authority to find out whether one backflow preventer may be used for tanks or each tank must be equipped with its own backflow preventer. If each tank must have its own backflow preventer, each tank must also have its own expansion tank. If a common backflow preventer is permitted, an expansion tank must be sized to accommodate the expansion volume of all tanks.

### Domestic water piping for distant fixtures

In some cases the furthest fixture may be quite distant from the tank. Such an installation would result in an unacceptable delay before hot water reaches these distant fixtures. Even if all the fixtures are relatively close to the tank, the building owner may want hot water at all fixtures as soon as they are opened.

To prevent delays, return circulation piping with a check valve that allows flow to the inlet of the tank. This should be installed on each branch circuit at the farthest fixture or device, so that hot water is supplied upon demand.

Because hot water is always circulating in the hot water branch, the entire branch should be insulated to prevent excessive heat loss.

## 4 Domestic side (tank) piping

### Anti-scald valves (mixing valves)

Anti-scald valves used with water heaters are also called tempering valves or mixing valves. An anti-scald valve mixes cold water in with the outgoing hot water to assure that hot water reaching a building fixture is at a temperature low enough to be safe. ASSE1017 and ASSE1070 certified valves are recommended.

Usually, the maximum temperature of the outlet water will stay near the setting of the tank control. In some cases, however, hot water usage patterns can cause the outlet water temperature to rise significantly above the control setting.

The temperature of water going to the fixtures may be more carefully controlled through the use of a thermostatic mixing valve. This device blends a controlled amount of cold water with the hot water leaving the tank so that water at a more constant temperature exits the mixing valve. Anti-scald mixing valve piping is illustrated in FIG.'s 3-1 thru 3-4.

**WARNING** An anti-scald mixing valve does not eliminate the risk of scalding.

- \* Set the tank thermostat as low as practical.
- \* Feel water before bathing or showering.
- \* If anti-scald or anti-chill protection is required, use devices specifically designed for such service. Install these devices in accordance with their manufacturer's instructions.


### Install drain valve

Drain valve and fittings are supplied by others.

#### Standard Installation

- Install a tee connection at the domestic cold water inlet (FIG. 4-1).

**Figure 4-1 Drain Valve Installed**



### Temperature & pressure (T&P) relief valve

**WARNING** For protection against excessive temperatures and pressure, install temperature and pressure protective equipment required by local codes. This equipment shall not be less than a combination temperature and pressure relief valve certified by a nationally recognized testing laboratory that maintains periodic inspection of production of listed equipment or materials as meeting the requirements for Relief Valves and Automatic Gas Shutoff Devices for Hot Water Supply Systems, ANSI Z21.22 and the Standard CAN1-4.4, Temperature, Pressure, Temperature and Pressure Relief Valves and Vacuum Relief Valves. The combination temperature and pressure relief valve shall be marked with a maximum set pressure not to exceed the maximum working pressure of the water heater. The combination temperature and pressure relief valve shall also have an hourly rated temperature steam BTU discharge capacity not less than shown in Table 4A.

Install the combination temperature and pressure relief valve into the opening provided and marked for this purpose on the water heater.

**NOTICE** Verify that the combination temperature and pressure relief valve complies with local codes. If the combination temperature and pressure relief valve does not comply with local codes, replace it with one that does. Follow the installation instructions in this section.

Do not place a valve between the combination T&P relief valve and the tank.

Determine T&P relief valve size by the following specifications, unless they conflict with local codes:

- GIT040/050 - 3/4" NPT with a minimum CSA Rating of 105,000 Btu/hr.
- GIT080/119 - 3/4" NPT with a minimum CSA Rating of 205,000 Btu/hr.

**NOTICE** The Lochinvar GIT series water heaters will absorb/store less than 205,000 Btu/hr when domestic water outlet temperature is 210°F and boiler water supply temperature is 240°F. Listed outputs are based on ASME Section VIII Interpretation VIII-1-86-136. Check with local codes for applicability.

## 4 Domestic side (tank) piping *(continued)*

Model	Btu/hr
GIT040	105,000
GIT050	105,000
GIT080	205,000
GIT119	205,000

### Standard installation

- Install the T&P relief valve in the connection marked "Relief Valve".

### T&P relief valve discharge piping

T&P relief valve discharge piping MUST be:

- made of material serviceable for a temperature of 250°F or greater.
- directed so that hot water flows away from all persons.
- directed to a suitable place for disposal.
- installed so as to allow complete draining of the T&P relief valve and discharge line.
- terminated within 6" of the floor.

T&P relief valve discharge piping MUST NOT be:

- excessively long. Using more than two (2) elbows or 15 feet of piping can reduce discharge capacity.
- directly connected to a drain. Refer to local codes.
- subject to freezing.

### ⚠ WARNING

Do not install any valve between the T&P relief valve and the tank connection or on the T&P relief valve discharge piping. Improper placement and piping of T&P relief valve can cause severe personal injury, death or substantial property damage.


### ⚠ CAUTION

The T&P relief valve is not intended for constant duty, such as relief of pressure due to repeated normal system expansion. Correct this condition by installing a properly sized expansion tank in a domestic water system. Refer to the expansion tank manufacturer's installation instructions for proper sizing.

### ⚠ WARNING

Failure to install and maintain a new, listed 3/4" X 3/4" T&P relief valve will release the manufacturer from any claim which might result from excessive temperature and pressures.

**Figure 4-2 Recommended Domestic Water Piping**



### NOTICE

Please note that these illustrations are meant to show system piping concept only, the installer is responsible for all equipment and detailing required by local codes.

## 5 Wiring

### Indirect water heater sensor setup (Knight boiler)



#### CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

#### NOTICE

The sensor supplied contains an Auto Reset High Limit (194°F).

#### Install tank sensor



The tank sensor is a dual sensor which controls the temperature of the tank from the boiler(see FIG. 4-1). The tank sensor has a built-in high temperature limit set at 194°F.

1. Install the sensor inside the tank as depicted in FIG. 5-1.
2. Connect the wire leads to the DHW Tank Sensor (AUX) connection point on the Knight boiler connection board (see FIG. 5-1).
3. The Knight boiler will automatically read the sensor and default the tank temperature setting to 125°F.
4. Adjust the tank setpoint program. Reference the Knight Installation and Operation Manual for a detailed explanation of the tank setpoint program.

#### Connect tank sensor

1. Turn OFF the power to the unit. Use wire strippers to strip one inch of insulation from the ends of each wire that will be spliced.
2. Splice the two ends of bare wire by twisting them together with a pair of electrical pliers. Turn the pliers three or four times to make a sufficient connection.
3. Attach a wire nut at the point where the two wires have been twisted together. Twist the wire nut until it fits snugly, or until it cannot be twisted any more.
4. Wrap the wire nut and the two wires with electrical tape to secure the connection. Cover any exposed wiring with electrical tape.

**Figure 5-1** Indirect Water Heater Controlled Using Tank Sensor




## 5 Wiring *(continued)*

### Indirect water heater controlled using Aquastat and zone circulator / valve

1. Install Aquastat to tank. Aquastat control (100208546) can be ordered from your local Lochinvar distributor.
2. Connect Aquastat to the zone controller for the Indirect Water Heater Zone.
3. Adjust Aquastat to the desired temperature.

**Figure 5-2** Wiring for Zone Control



## 6 Start-up and check-out

1. Make sure the system is free of leaks and that air is purged from the system.

**CAUTION**

Fix any leaks found before proceeding further. Leakage from the boiler piping can result in severe damage to the boiler.

2. After completing all domestic water connections, flush the indirect water heater thoroughly before leaving the installation. This is particularly important if the indirect water heater will be unused for an extended period of time after installation. Flush the indirect water heater by drawing at least three times its volume from the tank.
3. Make sure that all electrical connections are made correctly and that no exposed high voltage wiring is present.
4. Make sure that each zone valve or circulator operates when, and only when, its thermostat calls for heat. Let each zone operate long enough to purge any remaining air from the system.
5. Set the indirect water heater to the desired temperature. Because hot water presents a scald hazard, it is best to set the thermostat at 120°F or lower and raise it only if necessary to provide adequate hot water.
6. Re-enable the burner and allow the boiler to operate. Make sure that the boiler shuts down when the indirect water heater is satisfied.

## 7 Maintenance

The Lochinvar GIT series indirect water heater is an extremely simple device and as such requires very little maintenance. There are, however, several items which should be checked out on an annual or as needed basis to ensure a reliable supply of hot water:

- \* Make sure that the rest of the boiler and domestic water piping is free of leaks.
- \* If there is an oil lubricated circulator in the system, make sure it is lubricated as called for by the circulator manufacturer.
- \* Make sure that the boiler is maintained in accordance with the boiler manufacturer's instructions.
- \* If a water treatment system is required to keep the water chemistry within the parameters shown in Table 2A (see Section 2 - Pre-Installation), make sure that this system is properly maintained.

### Maintenance Schedule

**Annual service by a qualified service technician should include the following:**

- Any procedure required by local codes.
- Verify system pressure. Air venting procedure may require adding water to bring boiler system up to pressure, typically 12 psig.
- Manually operate T&P relief valve at least once a year. This will release some hot water.

#### **⚠ WARNING**

Before operating a T&P relief valve, make sure no one is in front of or around the T&P relief valve discharge piping. Hot discharge water can cause severe personal injury or substantial property damage.

- Move operating lever to open position for a few seconds and then move it back, allowing it to snap closed. After the T&P relief valve is operated, if it continues to release water, close the cold water inlet to the water heater immediately. Follow the draining instructions, and replace the T&P relief valve. If the T&P relief valve weeps periodically, it may be due to thermal expansion. Do not plug the T&P relief valve or discharge piping.

#### **⚠ DANGER**

Plugging the T&P relief valve or discharge piping can cause excessive pressure in the water heater, resulting in severe personal injury, death, or substantial property damage.

- Follow instructions on circulator to oil, if required.
- Check mixing valve, valves, pipes, and fittings for leaks.
- Check function of the field-installed controls and valves. See component manufacturer's instructions.
- Review homeowner's maintenance responsibilities and their frequencies, including any not listed in the following section.

**Homeowner monthly maintenance to include:**

- Visually check valves, pipes, and fittings for leaks. Call a qualified service technician to repair leaks.

**To Fill the Water Heater**

1. Close the water heater drain valve by turning the knob clockwise.
2. Open the cold water supply shutoff valve.
3. Open several hot water faucets to allow air to escape from the system.
4. When a steady stream of water flows from the faucets, the water heater is filled. Close the faucets and check for water leaks at the water heater drain valve, combination temperature and pressure relief valve and the hot and cold water connections.

#### **⚠ WARNING**

Water from opened drain valves, unions and other connections may be extremely hot. To avoid severe personal injury, death, or substantial property damage:

- Tighten all drain hose connections.
- Direct hot water away from all persons.

**To Drain the Water Heater**

Should it become necessary to completely drain the water heater, be sure to follow the steps below:

1. Disconnect the power supply to the heat source. Consult the plumbing professional or electric company in your area for service.
2. Close the cold water supply shutoff valve.
3. Open the drain valve on the water heater.
4. Open a hot water faucet to allow air to enter the system.

Drain the water heater if it will be shut off and exposed to freezing temperatures. Freezing water will expand and damage the water heater.

- If boiler water contains sufficient antifreeze, then only the domestic water needs to be drained.
- If boiler water does not contain sufficient antifreeze, the boiler water and the domestic water must be drained.

If antifreeze is used in the boiler water, check concentration. Boiler water (including additives) must be practically non-toxic, having a toxicity rating or class of 1, as listed in the "Clinical Toxicology of Commercial Products". A maximum 50/50 mixture of inhibited propylene glycol is recommended. Follow the antifreeze manufacturer's instructions.

#### **⚠ WARNING**

Do not use automotive, ethylene glycol or petroleum-based antifreeze. Do not use any undiluted antifreeze. This can cause severe personal injury, death, or substantial property damage.

## 8 Performance data

Table 8A AHRI Chart

		Indirect Water Heater						
Indirect Water Heater Model Number	Potable Water Volume Gal.	Heat Source Water Volume Gal.	Standby Heat Loss F/hr	Continuous Draw Rating Gal/hr	First Hour Rating Gal/hr	Minimum Heat Output Rate from Heat Source Btu/hr	Minimum Heat Source Flow Rate GPM	Tank Heat Source Friction Loss Feet W.C.
<b>GIT040</b>	40	1.6	1	137	167	96,000	14	5.7
<b>GIT050</b>	50	1.9	1.3	182	227	132,000	14	5.8
<b>GIT080</b>	70	2.4	1.2	262	319	175,000	14	8.9
<b>GIT119</b>	115	2.8	0.5	294	389	197,000	14	16.4

• These ratings were obtained with a heat source output and heat source flow rate as listed in the chart using the parameters of the Domestic Cold Water Inlet at 58°F, Domestic Temperature Rise of 77°F, and a Boiler Temperature Output of 180°F. Other results will be obtained under different conditions.

## 8 Performance data *(continued)*

### How to properly Size Your Indirect Water Heater

Use the First Hour Rating (FHR) to properly size your Indirect Water Heater. The First Hour Rating is the amount of hot water in gallons the heater can supply per hour (starting with a tank full of hot water), depending on tank capacity, source of heat, and the size of the burner.

#### Estimate your peak hour demand as follows:

- Determine what time of day (morning, noon, evening) you use the most hot water in your home. Keep in mind the number of people living in your home.
- Use the worksheet below to estimate your maximum usage of hot water during this one hour of the day -- this is your peak hour demand. Note: The worksheet does not estimate total daily hot water usage.

The worksheet example shows a total peak hour demand of 165 gallons; therefore, this household would need a water heater with a First Hour Rating of no less than 165 gallons.

#### Fixture Count Guide

To quickly estimate the minimum gallons of hot water required based on a family size number of baths and hot water appliances the First Hour Rating of the Squire must be equal to or exceed the total first hour requirements.

Peak Hour Demand Worksheet				
Description	Fill in the Blank		Example	
40 Gallons for the first 2 people	_____	Gals.	<u>40</u>	Gals.
10 Gallons for each additional person	_____	Gals.	<u>20</u>	Gals.
20 Gallons for each bath after the first (consecutive bath)	_____	Gals.	<u>20</u>	Gals.
10 Gallons if dishwasher is used	_____	Gals.	<u>10</u>	Gals.
20 Gallons if clothes washer is used	_____	Gals.	<u>20</u>	Gals.
<b>TOTAL</b>	_____	Gals.	<b><u>110</u></b>	Gals.
Heavy Usage Buffer Use if family members take longer than average showers, etc.	<u>x 1.5</u>		<u>x 1.5</u>	
First Hour Rating	_____	Gals.	<b>165</b>	Gals.

Proceed to pages 21 – 23 of this manual to locate your Indirect Water Heater and Boiler in the sizing charts. Using the First Hour Rating calculated in this worksheet, locate your Indirect Water Heater and Boiler along with your First Hour Rating. This will also determine the flow needed between the Indirect Water Heater and Boiler.

## 8 Performance data *(continued)*

**Table 8B First Hour Rating - 180°F Boiler Loop Water (Universal Sizing)**

<b>First Hour Rating - 180°F Boiler Loop Water (Universal Sizing - 45,000 - 260,000 Btu/hr)</b>																
Model	GIT040								GIT050							
Circulator Flow GPM	5		8		12		16		5		8		12		16	
Domestic Outlet	115	140	115	140	115	140	115	140	115	140	115	140	115	140	115	140
Boiler Heating Capacity	40,000	98	76							126	103					
	60,000	136	103							165	131					
	70,000	155	117							185	145					
	100,000	168	126	191	142					233	179	244	187			
	120,000					212	157	212	157			271	206			
	140,000					222	164	240	177					293	221	310
MAX BTU INPUT	77,000		89,150		105,600		114,750		94,115		114,111		125,111		134,044	

<b>First Hour Rating - 180°F Boiler Loop Water (Universal Sizing - 45,000 - 260,000 Btu/hr)</b>																	
Model	GIT080								GIT119								
Circulator Flow GPM	5		8		12		16		5		8		12		16		
Domestic Outlet	115	140	115	140	115	140	115	140	115	140	115	140	115	140	115	140	
Boiler Heating Capacity	40,000	154	131							160	124	188	165				
	60,000	192	158							170	145	227	193				
	70,000	212	172							185	155	247	207				
	100,000	270	213							229	186	305	248				
	120,000	300	235	308	241					258	207	344	276				
	140,000			345	267	347	268	347	268	287	228	383	304				
	165,000							396	303	290	230			431	338		
	195,000							408	311					480	373	490	379
	225,000															509	393
	260,000																
MAX BTU INPUT	115,860		139,106		154,002		171,229		125,300		141,419		190,161		204,795		

## 9 Replacement parts

REPLACEMENT PARTS LIST	
PART NUMBER	DESCRIPTION
100208545	Thermostat, Sensor, -20+105C
100208546	Aquastat, 40-180°
100306392	Anode 11.81 (GIT040, GIT050)
100306396	Anode 17.71 (GIT080, GIT119)

# Notes

# Notes



**Revision Notes:** *Revision A (PCP# 3000024508 / CN# 500015339) initial release.*

*Revision B (PCP #3000026014 / CN #500015684) reflects an update to Table 3A on page 6, Table 8A on page 18, and Table 8B on page 20.*

*Revision C (PCP #3000047320 / CN #500034888) changes made to Table 3A on page 6 on Model GIT119 and Table 8A on page 18 on Model GIT119.*